



AEC PREMIER STRAW® HIGHWAY ROLLS MECHANICALLY INSTALLED ECB INSTALLATION GUIDELINES

Before installing AEC Premier Straw Highway Rolls, the seedbed shall be inspected by the Owner's Representative to ensure it has been properly compacted and fine graded to remove any existing rills. It shall be free of obstructions, such as tree roots, projections such as stones, and other foreign objects. The contractor shall proceed when satisfactory conditions are present. After the area has been properly shaped, seeded, fertilized, and compacted, AEC Premier Straw Highway Roll's outside wrapping shall be removed. Next, locate the start of the roll, making sure the roll is facing toward the area to be covered, and then roll out blanket. The blankets shall be rolled out flat, even, and smooth without stretching the material then anchored to the subgrade.

Slopes: It is recommended the blankets be installed vertically on the slope; however, on short slopes it may be more practical to install horizontally across the width of the application. If more than one width is required, overlap the edges and secure the blankets with a common row of staples. AEC Premier Straw Highway Rolls shall be trenched at the head of the slope if the blanket cannot be extended three feet over the slope crest or if overland flow is anticipated from upslope areas.

Channels: AEC Premier Straw Highway Rolls shall be centered to offset a seam in the middle of the waterway. They shall be installed in the same direction as the water flow. The adjoining blankets shall be installed away from the center of channel and overlapped. Blanket installation should continue up the side slopes three feet above the anticipated high water elevation. Flanks exposed to runoff, or sheet flow, must be trenched in. AEC Premier Straw Highway Rolls shall be trenched at the start of the channel and anchored using a staggered staple pattern at end of roll overlaps and end of roll terminations.

The AEC Premier Straw Highway Rolls shaft installation device shall be mounted on standard construction equipment (e.g., skid steer loader or tractor). Safe operating limits of the equipment shall dictate the steepness limits to which AEC Premier Straw Highway Rolls can be mechanically installed. In no case shall the safe operating limits of the equipment be exceeded. Do not stand within the operating swing arm radius.

Disclaimer: AEC Premier Straw Highway Rolls is a system for erosion control and re-vegetation on slopes and channels. American Excelsior Company (AEC) believes that the information contained herein to be reliable and accurate for use in erosion control and revegetation applications. However, since physical conditions vary from job site to job site and even within a given job site, AEC makes no performance guarantees and assumes no obligation or liability for the reliability or accuracy of information contained herein for the results, safety, or suitability of using AEC Premier Straw Highway Rolls, or for damages occurring in connection with the installation of any erosion control product whether or not made by AEC or its affiliates, except as separately and specifically made in writing by AEC. These guidelines are subject to change without notice.