


AEC Premier Coconut™ Staple Pattern Guide

For 8' wide AEC Premier Coconut Erosion Control Blankets

Application	Slope		Channel
	≤ 3:1	≤ 1:1	≤2.25 lb/ft ² (108 Pa) Shear Stress ≤9.0 ft/sec (2.7 m/sec) Velocity
Staple Pattern	A	B	B

○ = Staple Placement



Notes:

1. Recommended staples are a minimum 4" biodegradable E-Staple®, as provided by American Excelsior Company, or 6" wire for cohesive soils and 6" biodegradable E-Staple®, as provided by American Excelsior Company, or 8" wire for non-cohesive soils.

2. Adjust staple pattern so staples are placed in critical channel points (e.g. slope interface, channel bottom) as illustrated below:

Critical channel points are circled.

