


AEC Premier Straw/CoconutTM Staple Pattern Guide

For 8 ft wide AEC Premier Straw/Coconut Erosion Control Blankets



Application	Slope	
	≤ 3H:1V	≤ 1.5H:1V
Staple Pattern	A	B

● = Staple Placement



Notes:

1. Recommended staples are minimum 4 in biodegradable E-Staple[®], as provided by American Excelsior Company, or 6 in wire for cohesive soils and 6 in biodegradable E-staple[®], as provided by American Excelsior Company, or 8 in wire for non-cohesive soils.
2. For best results, insert staples so heads are parallel to the flow of water.
3. For additional pull-out resistance, consider using TL-TA2 Gripple twist anchors for tough/cohesive soils or TL-TA1 Gripple twist anchors for moderate/non-cohesive soils.



**American
Excelsior
Company[®]**
Earth Science Division

AMERICAN EXCELSIOR COMPANY
ARLINGTON, TEXAS

SHEET DESCRIPTION
AEC PREMIER STRAW/COCONUTTM
SLOPE APPLICATION DETAIL

DATE 11/22/23
SCALE
NONE

DRAWN BY
PROJECT NO.
SHEET NO.
11